

Item	Part Number	Description	Q. ty by Pump	H300	H300RL	H400	H400RL	HC450	HC450RL	HC450IRL	HC500	HC500RL	HC500IRL	HC500SIRL	HC530RL	HC550	HC550IRL	HC570IRL	HC580RL	
34	0301.02	Shim	1																	
*35	1800.01	Plunger bolt	3																	
*36	1400.12	Copper spacer	3																	
*37	0601.03	"O" Ring Ø1.78x7.66	3																	
*38	0000.04	Teflon ring	3																	
*39	1200.10	Plunger 20mm	3																	
*40	1400.15	Copper spacer	3																	
41	0003.01	Plunger rod	3																	
42	0100.01	Connecting rod	3	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*
43	1502.01	Connecting rod pin	3																	
44	1801.05	Connecting rod screw	6																	
45	1500.01	Snap ring	6																	
46	1401.02	Spring washer	6																	
47	0600.09	Cover gasket	1																	
48	0203.17	Crankcase cover	1																	
49	0603.02	Gasket, G3/8	1																	
50	0700.01	Sight glass, G3/8	1																	
51	1801.12	Cover screw	5																	

Included Positions	Part Number & Description	Q. ty by Pump	H300	H300RL	H400	H400RL	HC450	HC450RL	HC450IRL	HC500	HC500RL	HC500IRL	HC500SIRL	HC530RL	HC550	HC550IRL	HC570IRL	HC580RL	
4- 5- 7	2808.01 Plunger Seals 20mm	1																	
3- 4- 5- 6- 7- 8	2808.00 Complete Seals Packing 20mm	3																	
35- 36- 37- 38 39- 40	2808.02 Plunger 20mm	3	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*
12- 13- 14	2800.08 Complete Valve	6																	
3	2808.03 Plunger oil Seals	1																	
4- 5- 6- 7- 8- 9 10- 11- 12- 13 14- 15- 18- 19	2808.13 Complete Manifold	1	*	*	*	*	*	*	*	*	*	*							
	2808.14 Complete Manifold	1											*	*	*	*	*	*	